


Assembly and Operating Manual

GWK

Gripper Changing Head



Superior Clamping and Gripping



Imprint

Copyright:

This manual is protected by copyright. The author is SCHUNK GmbH & Co. KG. All rights reserved.

Technical changes:

We reserve the right to make alterations for the purpose of technical improvement.

Document number: 389127

Version: 05.00 | 05/01/2023 | en

Dear Customer,

Thank you for trusting our products and our family-owned company, the leading technology supplier of robots and production machines.

Our team is always available to answer any questions on this product and other solutions. Ask us questions and challenge us. We will find a solution!

Best regards,

Your SCHUNK team

Customer Management

Tel. +49-7133-103-2503

Fax +49-7133-103-2189

cmg@de.schunk.com



Please read the operating manual in full and keep it close to the product.

Table of Contents

1	General.....	5
1.1	About this manual.....	5
1.1.1	Presentation of Warning Labels.....	5
1.1.2	Applicable documents	6
1.2	Warranty.....	6
1.3	Scope of delivery.....	6
1.3.1	Accessories kit.....	6
1.4	Accessories.....	7
1.4.1	Seal kit.....	7
1.4.2	Sensors.....	7
1.4.3	Customizable plug connector – 12-pin	8
2	Basic safety notes	9
2.1	Intended use	9
2.2	Not intended use	9
2.3	Constructional changes.....	9
2.4	Spare parts	9
2.5	Ambient conditions and operating conditions.....	10
2.6	Personnel qualification	10
2.7	Personal protective equipment	11
2.8	Notes on safe operation	11
2.9	Transport.....	11
2.10	Malfunctions	12
2.11	Disposal.....	12
2.12	Fundamental dangers	12
2.12.1	Protection during handling and assembly	13
2.12.2	Protection during commissioning and operation	13
2.12.3	Protection against dangerous movements.....	14
2.12.4	Protection against electric shock	14
2.13	Notes on particular risks	15
3	Technical data.....	16
4	Assembly	17
4.1	Mechanical connection	17
4.2	Electrical plug connector.....	21
4.3	Mounting the sensor.....	23
4.3.1	Inductive proximity switch IN 80	24
5	Troubleshooting	26

6	Maintenance	27
6.1	Notes.....	27
6.2	Maintenance intervals	27
6.3	Lubricants/Lubrication points (basic lubrication)	27
6.4	Disassembly of the module	28
6.5	Servicing and assembling the module.....	29
	6.5.1 Changing the socket part (20).....	29
6.6	Assembly drawing	30
7	Translation of the original declaration of incorporation	33
8	UKCA declaration of incorporation.....	34
9	Annex to declaration of Incorporation	35

1 General

1.1 About this manual

This manual contains important information for a safe and appropriate use of the product.

This manual is an integral part of the product and must be kept accessible for the personnel at all times.

Before starting work, the personnel must have read and understood this operating manual. Prerequisite for safe working is the observance of all safety instructions in this manual.

In addition to these instructions, the documents listed under ► 1.1.2 [6] are applicable.

NOTE: The illustrations in this manual are intended to provide a basic understanding and may deviate from the actual version.

1.1.1 Presentation of Warning Labels

To make risks clear, the following signal words and symbols are used for safety notes.



⚠ DANGER

Dangers for persons!

Non-observance will inevitably cause irreversible injury or death.



⚠ WARNING

Dangers for persons!

Non-observance can lead to irreversible injury and even death.



⚠ CAUTION

Dangers for persons!

Non-observance can cause minor injuries.

NOTICE

Material damage!

Information about avoiding material damage.

1.1.2 Applicable documents

- General terms of business *
- Catalog data sheet of the purchased product *
- Assembly and operating manuals of the accessories *

The documents labeled with an asterisk (*) can be downloaded from schunk.com.

1.2 Warranty

If the product is used as intended, the warranty is valid for 24 months from the ex-works delivery date under the following conditions:

- Observe the specified maintenance and lubrication intervals
- Observe the ambient conditions and operating conditions

Parts touching the workpiece and wear parts are not included in the warranty.

1.3 Scope of delivery

The scope of delivery includes

- Gripper Changing Head GWK in the version ordered
- Assembly and Operating Manual
- Accessory pack

1.3.1 Accessories kit

Content of the accessory pack:

- 1 x key
- Screws for mounting
- Swivel fittings
- 2 x cylindrical pin
- O-rings (from size 80)
- 1 x clamping ring (size 125)
- Elbow connectors (size 125)

ID.-No. of the accessory pack

Accessory pack for	ID number
GWK 64	5509671
GWK 80	5511254
GWK 125	5511235

1.4 Accessories

The following accessories, which must be ordered separately, are required for the product:

- Sensors
- Gripper change magazine

For information regarding which accessory articles can be used with the corresponding product variants, see catalog data sheet.

1.4.1 Seal kit

Content of the sealing kit:

- Quad ring
- O-rings
- Sealing rings

ID.-No. of the seal kit

Seal kit for	ID number
GWK 64	0370565
GWK 80	0370566
GWK 125	0370567

1.4.2 Sensors


Overview of the compatible sensors

Designation	Type
Inductive proximity switches	IN

- Exact type designation of the compatible sensors see catalog.
- Information on handling sensors is available at schunk.com or from SCHUNK contact persons.

1.4.3 Customizable plug connector – 12-pin

Additional attachment on request for gripper change systems GWS 64, 80 and 125.



Connector part – 12-pin	5510905
Socket part – 12-pin	5510904

2 Basic safety notes

2.1 Intended use

The product is only intended to be used for automatic changing of robot tools (e.g. grippers, pneumatically or electrically driven tools, electrode holders etc.).

- The product may only be used within the scope of its technical data, ▶ 3 [16].
- When implementing and operating components in safety-related parts of the control systems, the basic safety principles in accordance with DIN EN ISO 13849-2 apply. The proven safety principles in accordance with DIN EN ISO 13849-2 also apply to categories 1, 2, 3 and 4.
- The product is intended for installation in a machine/automated system. The applicable guidelines for the machine/automated system must be observed and complied with.
- The product is intended for industrial and industry-oriented use.
- Appropriate use of the product includes compliance with all instructions in this manual.

2.2 Not intended use

It is not intended use if the product is used, for example, as a pressing tool, stamping tool, lifting gear, guide for tools, cutting tool, clamping device or a drilling tool.

- Any utilization that exceeds or differs from the appropriate use is regarded as misuse.

2.3 Constructional changes

Implementation of structural changes

By conversions, changes, and reworking, e.g. additional threads, holes, or safety devices can impair the functioning or safety of the product or damage it.

- Structural changes should only be made with the written approval of SCHUNK.

2.4 Spare parts

Use of unauthorized spare parts

Using unauthorized spare parts can endanger personnel and damage the product or cause it to malfunction.

- Use only original spare parts or spares authorized by SCHUNK.

2.5 Ambient conditions and operating conditions

Required ambient conditions and operating conditions

Incorrect ambient and operating conditions can make the product unsafe, leading to the risk of serious injuries, considerable material damage and/or a significant reduction to the product's life span.

- Make sure that the product is used only in the context of its defined application parameters, ▶ 3 [□ 16].
- Make sure that the product is a sufficient size for the application.
- Make sure that the environment is free from splash water and vapors as well as from abrasion or processing dust. Exceptions are products that are designed especially for contaminated environments.

2.6 Personnel qualification

Inadequate qualifications of the personnel

If the personnel working with the product is not sufficiently qualified, the result may be serious injuries and significant property damage.

- All work may only be performed by qualified personnel.
- Before working with the product, the personnel must have read and understood the complete assembly and operating manual.
- Observe the national safety regulations and rules and general safety instructions.

The following personal qualifications are necessary for the various activities related to the product:

Trained electrician

Due to their technical training, knowledge and experience, trained electricians are able to work on electrical systems, recognize and avoid possible dangers and know the relevant standards and regulations.

Qualified personnel

Due to its technical training, knowledge and experience, qualified personnel is able to perform the delegated tasks, recognize and avoid possible dangers and knows the relevant standards and regulations.

Instructed person

Instructed persons were instructed by the operator about the delegated tasks and possible dangers due to improper behaviour.

Service personnel of the manufacturer

Due to its technical training, knowledge and experience, service personnel of the manufacturer is able to perform the delegated tasks and to recognize and avoid possible dangers.

2.7 Personal protective equipment

Use of personal protective equipment

Personal protective equipment serves to protect staff against danger which may interfere with their health or safety at work.

- When working on and with the product, observe the occupational health and safety regulations and wear the required personal protective equipment.
- Observe the valid safety and accident prevention regulations.
- Wear protective gloves to guard against sharp edges and corners or rough surfaces.
- Wear heat-resistant protective gloves when handling hot surfaces.
- Wear protective gloves and safety goggles when handling hazardous substances.
- Wear close-fitting protective clothing and also wear long hair in a hairnet when dealing with moving components.

2.8 Notes on safe operation

Incorrect handling of the personnel

Incorrect handling and assembly may impair the product's safety and cause serious injuries and considerable material damage.

- Avoid any manner of working that may interfere with the function and operational safety of the product.
- Use the product as intended.
- Observe the safety notes and assembly instructions.
- Do not expose the product to any corrosive media. This does not apply to products that are designed for special environments.
- Eliminate any malfunction immediately.
- Observe the care and maintenance instructions.
- Observe the current safety, accident prevention and environmental protection regulations regarding the product's application field.

2.9 Transport

Handling during transport

Incorrect handling during transport can make the product unsafe and risk the danger of serious injuries and considerable material damage.

- During transport and handling, secure the product to prevent it from falling.
- Do not walk under suspended loads.

2.10 Malfunctions

Behavior in case of malfunctions

- Immediately remove the product from operation and report the malfunction to the responsible departments/persons.
- Order appropriately trained personnel to rectify the malfunction.
- Do not recommission the product until the malfunction has been rectified.
- Test the product after a malfunction to establish whether it still functions properly and no increased risks have arisen.

2.11 Disposal

Handling of disposal

The incorrect handling of disposal may impair the product's safety and cause serious injuries as well as considerable material and environmental harm.

- Follow local regulations on dispatching product components for recycling or proper disposal.

2.12 Fundamental dangers

General

- Observe safety distances.
- Never deactivate safety devices.
- Before commissioning the product, take appropriate protective measures to secure the danger zone.
- Disconnect power sources before installation, modification, maintenance, or calibration. Ensure that no residual energy remains in the system.
- If the energy supply is connected, do not move any parts by hand.
- Do not reach into the open mechanism or movement area of the product during operation.

2.12.1 Protection during handling and assembly

Incorrect handling and assembly

Incorrect handling and assembly may impair the product's safety and cause serious injuries and considerable material damage.

- Have all work carried out by appropriately qualified personnel.
- For all work, secure the product against accidental operation.
- Observe the relevant accident prevention rules.
- Use suitable assembly and transport equipment and take precautions to prevent jamming and crushing.

Incorrect lifting of loads

Falling loads may cause serious injuries and even death.

- Stand clear of suspended loads and do not step into their swiveling range.
- Never move loads without supervision.
- Do not leave suspended loads unattended.

2.12.2 Protection during commissioning and operation

Falling or violently ejected components

Falling and violently ejected components can cause serious injuries and even death.

- Take appropriate protective measures to secure the danger zone.
- Never step into the danger zone during operation.

2.12.3 Protection against dangerous movements

Unexpected movements

Residual energy in the system may cause serious injuries while working with the product.

- Switch off the energy supply, ensure that no residual energy remains and secure against inadvertent reactivation.
- Never rely solely on the response of the monitoring function to avert danger. Until the installed monitors become effective, it must be assumed that the drive movement is faulty, with its action being dependent on the control unit and the current operating condition of the drive. Perform maintenance work, modifications, and attachments outside the danger zone defined by the movement range.
- To avoid accidents and/or material damage, human access to the movement range of the machine must be restricted. Limit/prevent accidental access for people in this area due through technical safety measures. The protective cover and protective fence must be rigid enough to withstand the maximum possible movement energy. EMERGENCY STOP switches must be easily and quickly accessible. Before starting up the machine or automated system, check that the EMERGENCY STOP system is working. Prevent operation of the machine if this protective equipment does not function correctly.

2.12.4 Protection against electric shock

Possible electrostatic energy

Components or assembly groups may become electrostatically charged. When the electrostatic charge is touched, the discharge may trigger a shock reaction leading to injuries.

- The operator must ensure that all components and assembly groups are included in the local potential equalisation in accordance with the applicable regulations.
- While paying attention to the actual conditions of the working environment, the potential equalisation must be implemented by a specialist electrician according to the applicable regulations.
- The effectiveness of the potential equalisation must be verified by executing regular safety measurements.

2.13 Notes on particular risks



⚠ DANGER

Risk of fatal injury from suspended loads!

Falling loads can cause serious injuries and even death.

- Stand clear of suspended loads and do not step within their swiveling range.
- Never move loads without supervision.
- Do not leave suspended loads unattended.
- Wear suitable protective equipment.



⚠ WARNING

Risk of injury from objects falling and being ejected!

Falling and ejected objects during operation can lead to serious injury or death.

- Take appropriate protective measures to secure the danger zone.



⚠ WARNING

Risk of injury due to unexpected movements!

If the power supply is switched on or residual energy remains in the system, components can move unexpectedly and cause serious injuries.

- Before starting any work on the product: Switch off the power supply and secure against restarting.
- Make sure, that no residual energy remains in the system.



⚠ WARNING

Risk of injury from sharp edges and corners!

Sharp edges and corners can cause cuts.

- Use suitable protective equipment.

3 Technical data

	GWK 64	GWK 80	GWK 125
Weight [kg]	0.5	0.65	2.3
Max. payload [kg]	60	86	170
Pneumatic energy transmission	4x M5 and 2x G1/8"	6x M5 and 2x G1/8"	8x G1/8" and 2x G1/4"
Electrical energy transmission	2 x 18 pins 60V/1A		
Min./max. distance during locking [mm]	2		
Max. permissible XY axis offset [mm]	1.5		
Max. permissible angle offset [°]	1		
Repeatability [mm]	0.02		
Noise emission [dB(A)]	≤ 70		

More technical data is included in the catalog data sheet.
Whichever is the latest version.

4 Assembly

4.1 Mechanical connection

Evenness of the mounting surface

The values apply to the whole mounting surface to which the product is mounted.

Requirements for evenness of the mounting surface (Dimensions in mm)

Edge length	Permissible unevenness
< 100	< 0.02
> 100	< 0.05


NOTE

If fitted with inductive proximity switches, these have to be inserted and mounted before the GWK is mounted.

Options for mounting the GWK:


- Centering shoulder and one cylindrical pin
- Two cylindrical pins

GWK 64




GWK 64

GWK 80



GWK 80

GWK 125



GWK 125

4.2 Electrical plug connector

NOTE

The cables must not be constantly moved up to the cable exit (risk of fracture).

The last cable clip is to be placed 100 – 300mm before the cable exit.


The minimum bending radius of the cable is 15 x cable \varnothing .

The bending radius can be less than the minimum where the cable is laid in such a way that it is rigid.

NOTE

The cable diameter is 8.5mm. The cable housing and plug connector are designed in accordance with VDE directives.

Connector assignments



Connector assignment – 18-pin

1	not assigned	11	blue
2	white-yellow	12	red
3	yellow-brown	13	black
4	white-gray	14	purple
5	gray-brown	15	gray-red
6	white-green	16	red-blue
7	brown-green	17	white
8	yellow	18	brown
9	gray	19	green
10	pink		

Cable types

18-pin	Lapp unitronic FD-D 18x0.14mm ²
3-pin	Lapp Ölflex 500 P 3x1.5mm ²
4-pin	Lapp Ölflex 500 P 4x2.5mm ²

4.3 Mounting the sensor


NOTE

Observe the assembly and operating manual of the sensor for mounting and connecting.

The product is equipped for the use of sensors.

- For the exact type designations of suitable sensors, please see the catalog data sheet.
- For technical data for the suitable sensors, see Assembly and Operating Manual and catalog data sheet.
 - The Assembly and Operating Manual and catalog data sheet are included in the scope of delivery for the sensors and are available at schunk.com.
- Information on handling sensors is available at schunk.com or from SCHUNK contact persons.

4.3.1 Inductive proximity switch IN 80



Connection example for IN 80

1	brown	2	black	3	blue
---	-------	---	-------	---	------

The inductive proximity switches used are equipped with reverse polarity protection and are short-circuit-proof.


Make sure that you handle the proximity switches properly:

- Do not pull on the cable.
- Do not allow the sensor to dangle from the cable.
- Do not overtighten the mounting screw or mounting clip.
- Please adhere to a permitted bend radius of the cable. (→ catalog)
- Avoid contact of the proximity switches with hard objects and with chemicals, in particular nitric acid, chromic acid and sulphuric acid.

The inductive proximity switches are electronic components, which can react sensitively to high-frequency interference or electromagnetic fields.

- Check to make sure that the cable is fastened and installed correctly. Provide for sufficient clearance to sources of high-frequency interference and their supply cables.
- Parallel switching of several sensor outputs of the same type (npn, pnp) is permissible, but does not increase the permissible load current.
- Note that the leakage current of the individual sensors (ca. 2 mA) is cumulative.

Installing the proximity switches for coding



1. Loosen the threaded ring with the key.
2. Slide proximity switch into the opening for the proximity switch in the direction of the arrow.
3. Secure the proximity switch with the threaded ring.
4. Connect all proximity switches and test the function.

5 Troubleshooting

Errors	Possible cause / Corrective action
GWK does not lock	<ul style="list-style-type: none"> • Check air supply. • Air or control line swapped
GWK does not lock properly	<ul style="list-style-type: none"> • Contact surface between GWK and GWA is dirty • Joint tolerances exceeded • Connections for plug connector are bent (joint tolerances).
GWK does not unlock properly	<ul style="list-style-type: none"> • Guide between piston and clamping pin broken • Unlocking pressure < 4.5 bar
Gripping force gets weaker	<ul style="list-style-type: none"> • Check seals • Check air pressure

6 Maintenance

6.1 Notes

The piston, clamping pins and taper are calibrated to each other in the housing.

To replace these parts, send the entire GWK to SCHUNK with a repair order.

It is useful to have SCHUNK perform maintenance and replace seals because the piston and clamping pins have to be aligned when assembled.

6.2 Maintenance intervals

NOTICE

Material damage due to hardening lubricants!

Lubricants harden more quickly at temperatures above 60°C, leading to possible product damage.

- Reduce the lubricant intervals accordingly.

Size	64 - 125
Interval [Mio. cycles]	2

6.3 Lubricants/Lubrication points (basic lubrication)

SCHUNK recommends the lubricants listed.

During maintenance, treat all greased areas with lubricant. Thinly apply lubricant with a lint-free cloth.

Lubricant point	Lubricant
Metallic sliding surfaces	Molykote BR 2 plus
All seals	Renolit HLT 2

6.4 Disassembly of the module

Position of the item numbers ▶ 6.6 [□ 30]



⚠ WARNING

Risk of injury due to unexpected movements!

If the power supply is switched on or residual energy remains in the system, components can move unexpectedly and cause serious injuries.

- Before starting any work on the product: Switch off the power supply and secure against restarting.
- Make sure, that no residual energy remains in the system.

1. Remove the pressure lines and socket parts (20). Disconnect the plug connector for the proximity switch.
2. Unscrew the GWK from the handling unit.



⚠ WARNING

Risk of injury due to components being ejected!

The GWK is fitted with a clamping force safety device. A fault can result in the bottom (2) being under spring tension.

- Disassemble the GWK carefully.

3. Carefully clamp the GWK between items "a" and "b".
4. Remove two screws (17) and slowly unclamp the GWK.

NOTE

The piston and clamping pins are calibrated to each other. Mark the installation position of these parts in the housing.

5. Remove the bottom (2) from the housing. Items 11 and 13 are also removed in the process.

6.5 Servicing and assembling the module

Maintenance

- Clean all parts thoroughly and check for damage and wear.
- Treat all greased areas with lubricant.
 - ▶ 6.3 [□ 27]
- Oil or grease bare external steel parts.
- Replace all wear parts / seals.
 - Position of the wearing parts ▶ 6.6 [□ 30]
 - Seal kit ▶ 1.4.1 [□ 7]
- The contact surfaces on the GWK gripper changing head, the pins and the centering taper for the connector parts must always be clean.
- Make sure that connector parts have noticeable axial and radial play.

If this is not the case, remove the connector parts, clean everything thoroughly and screw the connector parts back on.
- If the GWK gripper changing head is cleaned and maintained, the GWA gripper change adapter should also be cleaned thoroughly.

Assembly

Assembly takes place in the opposite order to disassembly. Observe the following:


- Unless otherwise specified, secure all screws and nuts with Loctite no. 243 and tighten with the appropriate tightening torque.

6.5.1 Changing the socket part (20)


1. Remove the screws (15) and replace the electrical plug connector (20).
2. Align the electrical plug connector parallel to surface "C" ▶ 6.6 [□ 30].

CAUTION! The electrical plug connector must not project beyond surface "C".


6.6 Assembly drawing



GWK 64 assembly



GWK 80 assembly



GWK 125 assembly

8 UKCA declaration of incorporation

in accordance with the Supply of Machinery (Safety) Regulations 2008.

Manufacturer/
Distributor SCHUNK Intec Limited
 Clamping and gripping technology
 3 Drakes Mews, Crownhill
 MK8 OER Milton Keynes

We hereby declare that on the date of the declaration the following partly completed machine complied with all basic safety and health regulations found in the "Supply of Machinery (Safety) Regulations 2008".

The declaration shall be rendered invalid if modifications are made to the product.

Product designation: Gripper Changing Head / GWK / pneumatic
ID number 0302506...0302536

The partly completed machine may not be put into operation until it has been confirmed that the machine into which the partly completed machine is to be installed complies with the provisions of the "Supply of Machinery (Safety) Regulations 2008".

Applied harmonized standards, especially:

EN ISO 12100:2010 Safety of machinery - General principles for design -
 Risk assessment and risk reduction

The manufacturer agrees to forward on demand the relevant technical documentation for the partly completed machinery in electronic form to national authorities.

The relevant technical documentation according to Annex VII, Part B, belonging to the partly completed machinery, has been created.

Person authorized to compile the technical documentation:
Marcel Machado, address: refer to manufacturer's address



Lauffen/Neckar, January 2023

p.p. Ralf Winkler;
Head of Technology & Engineering,
Mechanics Gripping Systems

9 Annex to declaration of Incorporation

in accordance with 2006/42/EC, Appendix II, no. 1 B

as well as

in accordance with the Supply of Machinery (Safety) Regulations 2008.

1. Description of the basic safety and health protection requirements, as per 2006/42/EC, Annex I and per the Supply of Machinery (Safety) Regulations 2008, that apply to and are fulfilled for the scope of the incomplete machine:

Product designation	Gripper Changing Head
Type designation	GWK
ID number	0302506...0302536

To be provided by the System Integrator for the overall machine	↓
Fulfilled for the scope of the partly completed machine	↓
Not relevant	↓


1.1	Essential Requirements		
1.1.1	Definitions	X	
1.1.2	Principles of safety integration	X	
1.1.3	Materials and products	X	
1.1.4	Lighting	X	
1.1.5	Design of machinery to facilitate its handling	X	
1.1.6	Ergonomics	X	
1.1.7	Operating positions		X
1.1.8	Seating		X

1.2	Control Systems		
1.2.1	Safety and reliability of control systems	X	
1.2.2	Control devices	X	
1.2.3	Starting	X	
1.2.4	Stopping	X	
1.2.4.1	Normal stop	X	
1.2.4.2	Operational stop	X	
1.2.4.3	Emergency stop	X	
1.2.4.4	Assembly of machinery	X	
1.2.5	Selection of control or operating modes	X	
1.2.6	Failure of the power supply		X

1.3	Protection against mechanical hazards		
1.3.1	Risk of loss of stability		X
1.3.2	Risk of break-up during operation		X

1.3	Protection against mechanical hazards			
1.3.3	Risks due to falling or ejected objects			X
1.3.4	Risks due to surfaces, edges or angles		X	
1.3.5	Risks related to combined machinery			X
1.3.6	Risks related to variations in operating conditions			X
1.3.7	Risks related to moving parts		X	
1.3.8	Choice of protection against risks arising from moving parts			X
1.3.8.1	Moving transmission parts		X	
1.3.8.2	Moving parts involved in the process			X
1.3.9	Risks of uncontrolled movements			X
1.4	Required characteristics of guards and protective devices			
1.4.1	General requirements			X
1.4.2	Special requirements for guards			X
1.4.2.1	Fixed guards			X
1.4.2.2	Interlocking movable guards			X
1.4.2.3	Adjustable guards restricting access			X
1.4.3	Special requirements for protective devices			X
1.5	Risks due to other hazards			
1.5.1	Electricity supply		X	
1.5.2	Static electricity		X	
1.5.3	Energy supply other than electricity		X	
1.5.4	Errors of fitting		X	
1.5.5	Extreme temperatures			X
1.5.6	Fire			X
1.5.7	Explosion			X
1.5.8	Noise			X
1.5.9	Vibrations			X
1.5.10	Radiation	X		
1.5.11	External radiation	X		
1.5.12	Laser radiation	X		
1.5.13	Emissions of hazardous materials and substances			X
1.5.14	Risk of being trapped in a machine	X		
1.5.15	Risk of slipping, tripping or falling	X		
1.5.16	Lightning			X
1.6	Maintenance			
1.6.1	Machinery maintenance		X	
1.6.2	Access to operating positions and servicing points		X	
1.6.3	Isolation of energy sources		X	

1.6	Maintenance			
1.6.4	Operator intervention		X	
1.6.5	Cleaning of internal parts		X	
1.7	Information			
1.7.1	Information and warnings on the machinery		X	
1.7.1.1	Information and information devices		X	
1.7.1.2	Warning devices		X	
1.7.2	Warning of residual risks		X	
1.7.3	Marking of machinery	X		
1.7.4	Instructions	X		
1.7.4.1	General principles for the drafting of instructions	X		
1.7.4.2	Contents of the instructions	X		
1.7.4.3	Sales literature	X		
	The classification from Annex 1 is to be supplemented from here forward.			
2	Supplementary essential health and safety requirements for certain categories of machinery			X
2.1	Foodstuffs machinery and machinery for cosmetics or pharmaceutical products			X
2.2	Portable hand-held and/or guided machinery			X
2.2.1	Portable fixing and other impact machinery			X
2.3	Machinery for working wood and material with similar physical characteristics			X
3	Supplementary essential health and safety requirements to offset hazards due to the mobility of machinery		X	
4	Supplementary essential health and safety requirements to offset hazards due to lifting operations		X	
5	Supplementary essential health and safety requirements for machinery intended for underground work			X
6	Supplementary essential health and safety requirements for machinery presenting particular hazards due to the lifting of persons		X	





SCHUNK GmbH & Co. KG
Clamping and gripping technology

Bahnhofstr. 106 - 134
D-74348 Lauffen/Neckar
Tel. +49-7133-103-0
Fax +49-7133-103-2399
info@de.schunk.com
schunk.com

Folgen Sie uns | *Follow us*

